

Gmini Antenna application note

Stubby and blade antennae should be located as far away from metal as possible.

Stubby antennae should be located more than 3cm away from metal and blade antennae more than 5cm.

Whip antennae should be located on a metal base, but the whip should be as far away from metal as possible.

See diagrams below:

